

ZTE N790

Quick Start Guide

Product Safety Information

	Do not use while re-fuelling
	Do not use hand-held while driving
	This device may produce a bright or flashing light
	For body-worn operation maintain a separation of 15 mm
	Do not dispose of it in a fire
	Small parts may cause a choking hazard
	This device may produce a loud sound
	Avoid Extreme Temperatures
	Keep away from pacemakers and other personal medical devices
	Avoid any contact with liquid, keep it dry
	Switch off when instructed in hospitals and medical facilities
	Do not attempt to disassemble

	Switch off when instructed in air-crafts and airports
	Do not rely on this device for emer-gency communications
	Switch off in explosive environ-ments
	Only use approved accessories

Notes:

microSD logo is a trademark of the SD Card Association.



Notice

We offer self-service for our smart terminal device users. Please visit ZTE official website (at www.zte.com.cn) for more information on self-service and supported product models. This product is designed to support two SIM cards. You can install two SIM cards simul-taneously and have them both in standby. However, both SIM cards cannot be used at the same time for phone service or data service. When you're in a phone call using one SIM card, the other one will be unreach-able through phone call. Callers to that card's number may hear voice prompts such as

"The number you dialed is unreachable." or "The number you dialed is out of service area".

The above situation is caused by the phone design and has nothing to do with the network of your operator. This design can significantly reduce power consumption and improve your phone's standby time. In case of missing important phone calls, please contact your operator to enable services like missed call alerts.

Getting to Know Your Phone



Power Key

- Hold to select phone modes: Silent, Air-plane, or to power off.
- Press to switch your phone to Sleep mode.
- Press to wake up your phone.

Home Key

- Press to return to the Home Screen from any application or screen.
- Hold to see recently used applications.

Menu Key

Press to get the options on the current screen.

Back Key

Press to go to the previous screen.

Search Key

Press to start the Search application.

Volume Key


Press higher end of the key to turn the vol-ume up and the lower end of the key to turn it down.

Before Getting Started

1. Removing the back cover




2. Installing the SIM cards




- Caution:** Install your CDMA card into UIM slot 1. Install your 2G SIM card into GSM slot 2. UIM slot 1 is the main slot, SIM slot 2 is the auxiliary slot.

3. Installing the battery



4. Installing the memory card



Charging the battery



When you first get your new phone you'll need to charge the battery like this...

1. Connect the adapter to the charger jack.
2. Connect the charger to a standard AC wall outlet.
3. Disconnect the charger when the battery is fully charged.

Powering On/Off Your Phone

1. Make sure the SIM is in your device and the battery is charged.
2. Hold **Power Key** to switch on your phone.
3. To switch it off, hold **Power Key** to get the phone options. Select **Power off**, and then tap **OK**.

Switching to Sleep Mode

To save battery power, Sleep Mode suspends your device to a low-power-consumption state while the display is off. Your device also goes into Sleep Mode automatically when the display is automatically turned off after a certain period of time, which you can set in **Screen timeout** of the display settings. Press **Power Key** to switch to Sleep Mode.

Waking Up Your Phone

If your phone is in Sleep Mode, you can wake it up by...

1. Pressing **Power Key** to activate your screen display.
2. Press and hold to unlock the screen.

Notes: If you have set an 'unlock pattern', or a PIN/password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock your screen.

Calls

Making Calls

1. Touch the **Home Key** > .
2. Enter the phone number with the on-screen keypad. Touch to delete wrong digits.
3. Touch **CDMA Call** or **GSM Call**.

Answering or Declining Calls

- Drag the green phone icon to the right.
- Drag to the left to decline a call.

Call forwarding

You can set your phone to forward incoming phone calls to another number. You can set this feature separately for several conditions when you are not able to answer calls, such as when you are already on the phone or when you are outside of the service area.

1. Touch the **Menu Key** > **Settings** > **Call settings** > **UIM Settings / SIM Settings** > **Call forwarding**.
2. Select a condition.
3. Enter a number to which calls will be forwarded and select **Enable**. Your setting will be sent to the network.

Call waiting

Call waiting gives you the option to take an incoming call when you're already on the phone. This function is available only for voice calls.

• CDMA Call waiting

1. Touch the **Menu Key > Settings > Call settings > UIM Settings > Call waitings.**
2. Select **Enable**, and then touch **Enable** to confirm. Your setting will be sent to the network.

• GSM Call Waiting

1. Touch the **Menu Key > Settings > Call settings > SIM Settings > Additional settings.**
2. Tick the checkbox at the right of the **Call waiting** to enable call waiting. Your setting will be sent to the network.

Contacts

Adding a New Contact

1. Open your contacts.
2. Touch  at the bottom on the screen.
3. If you have more than one account for contacts, touch **Contact type** and select the account to which you want to add the contact.

4. Enter the contact name and other information, such as phone numbers and emails.

Touch a category's plus button  to add more than one entry for that category—for example, to add both work and home numbers. Touch the button at the left of the entry to select labels, such as **Mobile** or **Work** for a phone number, or select **Custom** to create your own label.

5. Touch the picture frame icon  to assign a picture to the contact.

6. When you're finished, touch .

Importing Contacts From the CDMA/GSM Card

Contacts saved on the phone can have more information than just a name and a phone number, such as Email, contact icon, and address. If you've got contacts saved on the SIM card, you can import them to the phone.

1. Touch the **Home Key > .**
2. Touch the **Menu Key > Import/Export > Import from CDMA/GSM card.**
3. Touch all the SIM contacts you want to import and then touch .

Connect to networks

Connect to Wi-Fi network

1. From the home screen, touch **Menu Key > Settings > Wireless & networks.**
2. If Wi-Fi is not enabled, tick the checkbox at the right of the **Wi-Fi** to turn on Wi-Fi. The phone scans for available Wi-Fi networks and displays the names of those it finds.
3. Touch a network name to connect to it. You may need to enter a passeord.

Enable mobile data access

1. Touch the **Home Key > Menu Key > Settings > Wireless & networks > Mobile networks.**
2. Check **Data enabled** to enable data access over the mobile network.

Disable mobile data access

1. Touch the **Home Key > Menu Key > Settings > Wireless & networks > Mobile networks.**
2. Uncheck **Data enabled** to disable data access over the mobile network.

Use your phone as a hotspot

1. Press the **Home Key > Menu Key**, and touch **Settings > Wireless & networks > Tethering & portable hotspot.**

2. Check **Portable Wi-Fi hotspot**. After a moment, the phone starts broadcasting its Wi-Fi network name (SSID), so you can connect to it with up to 5 computers or other devices.
3. Touch **Portable Wi-Fi hotspot settings > Configure Wi-Fi hotspot** if you want to change the Wi-Fi network name or secure it with a password.

NOTE:

Uncheck **Portable Wi-Fi hotspot** to stop sharing your data connection via Wi-Fi.

Email

Email setup

1. From the home screen, touch  > **Email**.
NOTE:
If another email account is already set up, touch the **Menu Key > Account settings > ADD ACCOUNT**.
2. Enter the email address and password.
3. Touch **Next** and follow the onscreen instructions.

Create and send an email message

1. Press the **Menu Key** and touch **Compose**.
2. Address the message. As you enter text, matching addresses are offered from your Contacts. You can touch a suggested ad-

dress or enter a new one. Separate multiple addresses with commas.

3. Press the **Menu Key** and touch **Add Cc/Bcc** to address a copy or blind copy of the message.
4. Enter a subject for the message.
5. Enter the text to the message.
6. Press the **Menu Key** and touch **Add attachment** to send files with the message.
7. Touch **Send**.

Camera and video

Take a picture

1. From the home screen, touch  > **camera**.
2. Aim the camera at the subject and then touch  to take the shot.

Take a video

1. From the home screen, touch  > **camcorder**, or Drag  to the camcorder position in the camera interface.
2. Touch  to begin recording, touch  to stop.

Send a picture

1. From the home screen, touch  > **Gallery**.

2. Touch an album and then touch and hold a picture.
3. Touch **Share** and select a methord from the list.

Playing Music

You can play digital audio files from your phone's memory card in Music.

1. Touch the **Home Key >  > Music ** to open the Music Screen.
2. Select **Artists/Albums/Songs/Playlists /favorite** to find the songs you want to play.
3. Touch an item from the list to start playing.

NOTE: You can adjust the volume with the **Volume Keys**.



①	Touch to play the current playlist in shuffle mode, where tracks are played in random order.
②	Touch to toggle repeat mode: no repeat, repeat the current song, or repeat the current playlist.
③	Song and artist information.
④	Drag the slider to jump to any part of the song.
⑤	Tap to play the previous / rewind song.
⑥	Tap to add the current song to favorite.
⑦	Tap to open the current playlist.
⑧	Tap to pause or resume the track.
⑨	Tap to play the next song.

Moving an Application

You can move the applications downloaded or installed on your phone to the microSD card when the phone memory is full. You can also move applications to your phone if the microSD card is getting full.

NOTE: Not all applications can be move to your phone or microSD card.

- Touch the **Home Key >  > Settings > Applications > Manage applications.**
- Touch the application you want to move below the Downloaded tab.
- Touch Move to phone or Move to SD card.

Extending Battery Life

There are several things you can do to make your battery last longer.

- Turn on Wi-Fi, Bluetooth, GPS, mobile data, auto-sync only when you need to.
- Lower the screen brightness.
- Use Bluetooth tethering or USB tethering (when you have a cable) instead of portable Wi-Fi hotspot to share your phone's data service.
- From the home screen, touch  > **Task Manager** and close the apps you do not need but still run in the background.
- From the home screen, touch  > **Settings > Sound** and uncheck all **Feedback**.

Specific Absorption Rate (SAR)

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested was 0.356 W/kg. As mobile devices offer a range of functions, they can be used in other positions, such as on the body. As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum power required to communicate with the network.